
POLYWOOD

Assembly Instructions





20-Year Warranty

To view our full warranty, please visit **polywoodoutdoor.com/warranty**

Easily register your product using one of the methods below:

Text POLYWOOD to 71403


Receive a link to register online

— or —

Register on our website register.polywoodoutdoor.com

— or —

Send a Picture Take a photo of the icon below and text it to 71403 (US only)



NO ASSEMBLY REQUIRED

1710 Select Signature Chair



Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (833) 665-6300 or email support@polywoodoutdoor.com



• • • • • • • • • • • •

.....

Share your space

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook! #polywood



Watch & Learn

For assembly videos and more, visit **youtube.com/polywood**



Cleaning Tips

Even POLYWOOD gets dirty — here are some ways to help keep it clean:

For a quick clean:

Simply wipe down with soap and water.

For a deeper clean:

You'll need:

- » $\frac{1}{3}$ bleach and $\frac{2}{3}$ water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.