

Having Trouble?

If you have questions or concerns regarding assembly instructions or missing parts, please contact us at (833) 665-6300 or email support@polywoodoutdoor.com

.

.....

.....



Share your space

We love to see where our furniture ends up — snap a pic and share it on Instagram or Facebook! #polywood



POLYWOOD

Assembly Instructions



20-Year Warranty

To view our full warranty, please visit polywoodoutdoor.com/warranty

Easily register your product using one of the methods below:

Text POLYWOOD to 71403

Receive a link to register online

— or —

Register on our website register.polywoodoutdoor.com

— or —


Send a Picture Take a photo of the icon below and text it to 71403 (US only)



Watch & Learn

For assembly videos and more, visit **youtube.com/polywood**

NS48 Nautical 48" Swing





Cleaning Tips

Even POLYWOOD gets dirty – here are some ways to help keep it clean:

<u>For a quick clean:</u>

Simply wipe down with soap and water.

For a deeper clean:

You'll need:

- » $^{1\!\!/_3}$ bleach and $^{2\!\!/_3}$ water solution
- » clean cloth
- » soft bristle brush

Wipe on solution with your cloth and let it sit on the lumber for a few minutes (this will not affect the color). Then, loosen any dirt and debris that may catch in surface grooves with a soft bristle brush; hose down to rinse.

